CATEGORIES FOR DECLARED ARTICLES (Effective 1 May 2004)

A1	A2	
Appliance Connector	Arc Welding Machine	Power Supply or Charger
Bayonet Lampholder	Blanket	Projector
Bayonet Lampholder Adaptor	Bread Toaster	Range
Control or Conditioning Device	Clothes Dryer	Range Hood
Cord Extension Socket	Cooking Appliance - Portable Type	Razor/Hair Clipper
Cord-Line Switch	Dishwashing Machine	Refrigerator/Freezer
Decorative Lighting Outfit	Fan	Residual Current Device
Edison Screw Lampholder	Fence Energiser	Room Heater
Fluorescent Lamp Ballast	Flexible Heating Pad	Sewing Machine
Fluorescent Lamp Starter	Floor Polisher/Scrubber	Soldering Iron
Inspection Handlamp	Hair Care Appliance	Swimming Pool or Spa Equipment
Luminaire - Portable Type	Hedge Clipper	Television Receiver
Outlet Device	Immersion Heater	Therapeutic Lamp
Plug	Insect Electrocutor	Tool - Portable Type
Socket-Outlet	Iron	Vacuum Cleaner
Supply Flexible Cord	Kitchen Machine	Washing Machine
Wall Switch	Lawn Care Appliance	Water Bed Heater
	Liquid Heating Appliance	Water Heater - Pressure Storage Type
	Massage Appliance	
	Microwave Oven	
	Miniature Overcurrent Circuit-Breaker	

CATEGORIES FOR NON-DECLARED ARTICLES

S1	S2
Electrical components or accessories (being any apparatus, fixture, device, material or the like, used or intended for use as part of, or in connection with, an electrical installation, but not including appliances, luminaires or any declared article.) Luminaires (being complete lighting assemblies (excluding any declared article) intended to distribute, filter or transform the light from one or more lamps together with such components as ancillary equipment, shades, diffusers, reflectors and accessories, including the means of connection to supply circuit wiring, internal or interconnected wiring, and any associated housings.)	Other electrical articles (excluding any declared article.)